## **Stay-guides**

## For UNI-JET SCF and UNI-JET CC hinge-sides







Stay-guide SCF/CC – basic security						
SRW [mm]	L [mm]	LC-MA	PU	Order number		
390-419 [1]	590	-	10	6-39074-06-0-1		
420-500 [2]	590	-	10	6-39074-06-0-1		
501-750	590	-	10	6-39074-06-0-1		
751-1000	840	1	10	6-39074-08-0-1		
1001-1400 [3]	1040	1	10	6-39074-10-0-1		
Additional stay for Tilt&Turn [3][4]						
1201-1400	250	-	10	6-39731-00-0-1		
Additional stay for Tilt-First [3][4]						
1201-1400	250	-	10	6-39732-00-0-1		

- [1] If the centre fixing (at the connecting rod) is detached and removed from the connecting rod prior to assembly of the stay-guide (in conjunction with corner-drive S 6-32238 or corner-drive SLK 6-32224), the SRW can be reduced to 390–419 mm.
- [2] SRW 420–500 mm only possible in conjunction with corner-drive S 6-32238 or corner-drive SLK 6-32224. Installation according to drawing 0-45986.
- [3] Use auxiliary stay for SRW 1201–1400 mm (see page 203). Installation according to drawing 0-46684.
- [4] With PVC and aluminium windows it is necessary to use two profile-specific packers for each additional stay. For the appropriate order information refer to page 332 (PVC windows) and 572 (aluminium windows).
- When cropping the faceplate by less than 150 mm or when the notches are still visible after cropping, rod guide 8-00805 should be positioned at least 65 mm from the faceplate end.
- Optional comfort component for Tilt&Turn applications: Spacer for SCF stay-guide 9-46909. Installation according to drawing 0-47360.



Turn-Only stay-guide						
SRW [mm]	L [mm]	LC-MA	PU	Order number		
250-1400	250	-	10	6-39075-01-0-1		