


875 AC Z1 20 32

Icons: Worker, Warning, Slip, 630-631, www.camar.it/warning

Fe

30 1050 150



875 AC Z1 20 32 IP

Icons: Worker, Warning, Slip, 630-631, www.camar.it/warning

Fe

1000 1000

