




Angolo esterno 90° G38
90° external corner G38

Code	 pcs	 kg	 pcs
81/G38.A90AQ	25	0,45	50




Angolo interno 90° G38
90° internal corner G38

Code	 pcs	 kg	 pcs
81/G38.A90BQ	25	0,45	50




Angolo esterno 90° G39
90° external corner G39

Code	 pcs	 kg	 pcs
81/G39.A90AQ	25	0,5	50



Angolo interno 90° G39
90° internal corner G39

Code	 pcs	 kg	 pcs
81/G39.A90BQ	25	0,5	50



Angolo esterno 90° G38
90° external corner G38

Code	 pcs	 kg	 pcs
81/G38.A90AN	25	1,0	50